

DAQ Factory Installation Guide

Oxygenation & Water Management Specialists



Making your water better! **Point Four**
Systems Inc.

www.pointfour.com

103 - 16 Fawcett Road, Coquitlam BC V3K 6X9 CANADA

1-800-267-9936

Software Installation

System Disc

Contained on this CD are all the necessary programs and application files configured for your unit's specifications.

Follow this software guide to install the necessary components to configure your computer.

Files on CD:

- DAQ Factory Installation Guide
-
- DAQ Factory Application File
-
- Adobe PDF Reader Program



System Requirements



- Computer Specifications required (or needed) to run the Daq Factory:
 -
 - PC with 300 megahertz (MHz) or higher processor clock speed recommended; 233 MHz minimum required (single or dual processor system); Intel Pentium/Celeron family, or AMD K6/Athlon/Duron family, or compatible processor recommended
 -
 - 128 megabytes (MB) of RAM or higher recommended (64 MB minimum supported; may limit performance and some features)
 -
 - 1.5 gigabytes (GB) of available hard disk space
 -
 - Super VGA (800 x 600) or higher-resolution video adapter and monitor
 -
 - CD-ROM or DVD drive
 -
 - Keyboard and Microsoft Mouse or compatible pointing device
-

Software Installation

Installing DAQ Factory Program

The first step of the installation procedure is to install DAQ Factory

Insert CD,

Windows XP will automatically open the CD, displaying its content.

Double click the icon [DAQFactoryR5Inst.exe] to run the DAQ Factory Installation Wizard.




DAQFactoryR5Inst.exe



Read the license and agreement page, then check the [Yes, I agree with all the terms of this license agreement] by clicking it.




The next page contains information regarding installation over older versions of DAQ Factory and important information if your computer is set to automatically update Windows. Read this over carefully and click [Next].



Specify the folder DAQ Factory will be installed in.


The default is shown below: "c:\DAQFactory".



Software Installation


Installing DAQ Factory Program

Perform a [Runtime Only] installation.



Select all DAQ Factory components to be installed on your computer.

Press [Next] to continue.



Press [Next] to begin installation.



The following screen will track the installation's progress.

When the installation process is complete press the [Finish] button to exit Setup program.




Software Installation


Installing DAQ Factory Application File

The DAQFactory Application file is a program file specifically configured for your application controls.


Click [Start]
[My Computer]
double click on the [CD drive]
to display the file on the CD.



Within the CD file, right click the
[.ctl file] e.g. “daqfactorytest.ctl”
and select copy.
Select the [Back] button to
return to [My Computer].



Open [(C:) Hard Drive].
Open the [DAQ Factory] Program File.



Right click within the [DAQ Factory Program File] and paste the [.ctl file] in DAQ Factory.

The [.ctl file] will now be listed in the [DAQ Factory Program File].




Software Installation

Installing DAQ Factory Program

Navigate to C:\DAQFactory
under my computer


Right click the DAQ Factory Launch Icon and 1
select [Send to / Desktop (shortcut)] 2



Right click the DAQ Factory Shortcut Icon 1
select [Properties]

Under the [Shortcut] tab of the 2
[DAQ Factory Properties] window

Enter the [.ctl file] e.g. "daqfactorytest.ctl" 3
after the target address.



Make sure to put a **SPACE** before entering the
[.ctl file] into the target address.

Example:
(Before)

C:\DAQFacotry\DAQFactory.exe

(After)

C:\DAQFacotry\DAQFactory.exe daqfactorytest.ctl



Your application file (daqfactorytest.ctl) is now
assigned to DAQ Factory.

By clicking the DAQ Factory Shortcut Icon,
DAQ Factory will now launch with your
application file.

